



DMX Control Modes - S400 Color Panel C4

version 2.0 / 20201118

Standard	Advanced	Compressed RGBW	RGBW	Value	Function
1	1	7	*	0-255	Dimmer
*	2	*	*	0-255	Dimmer Fine
2	3	*	*	0-255	Shutter Duration
3	4	*	*	0-255	Shutter Flash Rate
4	5	6	*		SHUTTER Effects
				0-15	Reserved for Shutter Flash Rate Channel
				16-47	Shutter pulse (random effects / slow to fast)
				48-79	Ramp up (random effects / slow to fast)
				80-111	Ramp down (random effects / slow to fast)
				112-143	Ramp up & down (random effects / slow to fast)
				144-199	Strobe pause effect (slow to fast / 5s - 0.1s)
200-255	Reserved for Shutter Flash Rate Channel				
5	6	1	*	0-255	Color Wheel (See Color wheel Table)
6	7	2	1	0-255	RED
*	8	*	*	0-255	RED Fine
7	9	3	2	0-255	GREEN
*	10	*	*	0-255	GREEN Fine
8	11	4	3	0-255	BLUE
*	12	*	*	0-255	BLUE Fine
9	13	5	4	0-255	WHITE
*	14	*	*	0-255	WHITE Fine
10	15	*	*	0-255	CTO
11	16	*	*	0-255	Pattern
12	17	*	*	0-255	Pattern Speed
13	18	*	*	0-255	Control
14	19	*	*	0-255	Remote DMX Add.